

Main fuse A:

The main fuse A (1) is located behind the rear cowl.

The specified fuse is:

30A

1. Remove the rear cowl (page 45).
2. Disconnect the wire connector (2) of the starter magnetic switch.
3. Pull out the old fuse and install a new fuse.
The spare fuse (3) is located under the starter magnetic switch.
4. Reconnect the connector and install the rear cowl.


Main fuse B:

The main fuse B (4) is located under the seat.

The specified fuse is:

30A

1. Remove the seat (page 42).
2. Open the fuse box cover (5).
3. Pull out the old fuse and install a new fuse.
The spare fuse (3) is located under the starter magnetic switch.
4. Close the fuse box cover and install the seat.



- | | |
|---------------------|--------------------|
| (1) Main fuse A | (4) Main fuse B |
| (2) Wire connector | (5) Fuse box cover |
| (3) Spare main fuse | |