

## Is Your Scooter Ready to Ride?

---

Check these items after you get on the scooter:

- Throttle*      Rotate the throttle to check it moves smoothly without binding.
- Brakes*        Pull the front and rear brake levers to check that they operate normally.
- Indicators*    Turn the ignition on and check for normal operation of the gauges and indicators (page 17).

If you haven't ridden the scooter in over a week, you should also check other items, such as the oil level and other fluids. See *Periodic Maintenance* (page 72 ). Periodic maintenance should also be done at least once a month, no matter how often you ride.

Remember, be sure to take care of any problem you find, or have your Honda dealer correct it before you ride.