



Low Oil Pressure Indicator (red)

Lights when engine oil pressure is below the normal operating range. Should also light when the ignition switch is ON and the engine is not running. Should go off when the engine starts, except for occasional flickering at or near idling speed when engine is warm.

CAUTION:

- ***Running the engine with insufficient oil pressure may cause serious engine damage.***

CRUISE SET

Cruise Control Set Indicator

Lights when the cruise control set switch is pushed on (page 37).

Should also light for a few seconds and then go off when the ignition switch is turned ON.

WARNING


- ***The cruise control automates the function of the throttle; do not operate the cruise control while in traffic, on winding roads or in bad weather conditions.***

CRUISE ON

Cruise Control Master Switch Indicator

Lights when the cruise control master switch is pushed on (page 37).

Should also light for a few seconds and then go off when the ignition switch is turned ON.



Digital Clock Adjust Knob

Used to set the time on the digital clock (page 17).