


PARTS LOCATION

Fuel Gauge

The fuel gauge shows the approximate fuel supply available. At F (Full) there are 24.0 liters (5.3 Imp gal, 6.3 US gal), including the reserve supply.

When the gauge needle enters the red band, fuel will be low and you should refill the tank as soon as possible. The amount of fuel left in the tank when the needle enters the red band is approximately 3.6 liters (0.8 Imp gal, 0.9 US gal).



Coolant Temperature Gauge

When the needle begins to move above the C (Cold) mark, the engine is warm enough to operate. The normal operating temperature range is within the zone between the C and H marks. If the needle reaches the H (Hot) mark, stop the engine and check the reserve tank coolant level (page 24).

Do not ride the motorcycle until the problem has been corrected.

CAUTION:

- *Exceeding maximum running temperature may cause serious engine damage.*

