

Storing Your Honda

Removal from Storage

Refer to *Safety Precautions* on page 69.

1. Uncover and clean your Honda MUV.
2. If your Honda MUV has been stored for more than four months—change the engine oil (page 93).
3. If your Honda MUV has been stored for more than two months—ask your Honda dealer to drain and replace the fuel.
4. Charge the battery (page 148) as required. Install the battery.
5. Perform a pre-ride inspection (page 44), then test-drive your Honda MUV at low speeds.