

## TYRES

Maintaining proper tyre pressure will provide maximum traction, stability, riding comfort and tyre life.

See your authorized Honda dealer for repair or replacement of tyres.

### Pressure Check

Check tyre pressures frequently with a pressure gauge and adjust if necessary.

#### NOTE:

\* Tyre pressure should be checked before you ride, while the tyres are "cold".

Check the tyres for cuts, embedded nails, or other sharp objects. See your authorized Honda dealer for replacement of damaged tyres or punctured inner tubes.

		DK type	U type
Cold tyre pressures kPa (kg/cm <sup>2</sup> , psi)	FRONT	150 (1.5, 21)	125 (1.25, 18)
	REAR	175 (1.75, 24)	200 (2.00, 28)
Tyre size	FRONT	3.00-8-2PR	2.75-10-4PR
	REAR	3.00-8-2PR	2.75-10-4PR
The maximum weight capacity kg (lb)		82 (180)	