

## Front Suspension

The front suspension of this motorcycle is air-assisted to provide a comfortable ride under various riding conditions.

The recommended pressure is:

0–40 kPa (0–0.4 kg/cm<sup>2</sup>, 0–6 psi)

Check air pressure when the front fork tubes are cold before riding.

1. Place a support under the engine to raise the wheel off the ground.  
Do not use the side stand or you will get false pressure readings.
2. Remove the front fork air valve cap.
3. Check the air pressure using a pressure gauge (1).

**NOTE:** Some pressure will be lost when removing the gauge from the valve. Determine the amount of loss and compensate accordingly.

