



## Is Your ATV Ready to Ride?

---

- Fuel* Check the level and add fuel (page 130) if needed. Also make sure the fuel fill cap is securely fastened.  
Check for leaks.
- Tyres* Use a gauge to check the air pressure. Adjust if needed. Also look for signs of damage or excessive wear (page 180).
- Drivetrain Boots* Check for damage (page 189).
- Guards* Check for damage or looseness (page 187).
- Nuts & Bolts* Check the wheels to see that the axle nuts are tightened. Use a wrench to make sure all accessible nuts, bolts, and fasteners are tight.
- Underbody & Exhaust System* Check for, and remove, any dirt, vegetation or other debris that could be a fire hazard or interfere with the proper operation of the vehicle.
- Air Cleaner Housing Drain Tube* Check for deposits in the drain tube. If necessary, clean the tube (page 157) and check the air cleaner housing.
- Leaks, Loose Parts* Walk around your ATV and look for anything that appears unusual, such as a leak or loose cable.
- Cable* Check the cable housings for wear. Check the fittings for looseness. Replace or tighten as needed.
- Lights* Make sure the headlight, brake light and taillight are working properly.

### 62 Before Riding

