

Suspension

Suspension Adjustment

The suspension can be adjusted for rider weight and riding conditions by changing the rebound and compression damping.

The shock absorber assemblies includes a damper unit that contains high pressure nitrogen gas. Do not attempt to disassemble, service, or dispose of the damper; see your Honda dealer. The instructions found in this owner's manual are limited to adjustments of the shock assemblies.