

# If You Have a Flat Tyre

---

## Installation

1. Position the wheel.
2. Position the wheel nuts.
3. Tighten the wheel nuts in a crisscross (rather than a circular) pattern to the specified torque:  
**64 N·m (6.5 kgf·m , 47 lbf·ft)**

If a torque wrench was not used for installation, see your Honda dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capability.