

If Your Engine Quits or Won't Start

| SYMPTOM: Engine starts, but runs poorly. | |
|---|---|
| POSSIBLE CAUSE | WHAT TO DO |
| idles roughly, too fast, stalls | Check engine idle adjustment (page 132). If the problem persists, see your Honda dealer. |
| poor engine performance at altitudes above 1,000 m (3,000 feet) | Ask your Honda dealer to modify the carburetion with a high altitude jet. Refer to <i>High Altitude Carburetor Adjustment</i> , page 205. |
| high oil temperature | Check the high oil temperature indicator. Refer to <i>If the High Oil Temperature Indicator Lights</i> , page 188. |
| runs erratically, misfires | See your Honda dealer. |
| blubbers (rich fuel mixture) | See your Honda dealer. |
| sooty exhaust (rich fuel mixture) | See your Honda dealer. |
| detonates or pings under load | If applicable, switch to the recommended octane petrol (page 105) or change your brand of petrol. If the problem persists, see your Honda dealer. |
| afterfires (backfires) | See your Honda dealer. |
| pre-ignition (runs on after ignition switched OFF) | See your Honda dealer. |