

Adding Engine Oil

If the engine oil is below or near the lower level mark, add the recommended engine oil.

► P. 107

1. Add the recommended oil until it reaches the upper level mark.
 - Place your scooter on its centre stand on a firm, level surface when checking the oil level.
 - Do not overfill above the upper level mark.
 - Make sure no foreign objects enter the oil filler opening.
 - Wipe up any spills immediately.
2. Securely reinstall the oil fill cap/dipstick.

NOTICE

Overfilling with oil or operating with insufficient oil can cause damage to your engine. Do not mix different brands and grades of oil. They may affect lubrication.

For the recommended oil and oil selection guidelines, see "Maintenance Fundamentals." ► P. 51

Changing Engine Oil, Cleaning Strainer Screen

Changing the oil and cleaning the strainer screen requires special tools. We recommend that you have your scooter serviced by your dealer.

Change the engine oil with the Idling Stop switch IDLING.

1. Park your scooter on its centre stand on a firm, level surface.
2. If the engine is cold, idle the engine for 3 to 5 minutes.