

## Quick Reference

---

Break-in Maintenance	first week of operation, about 200 miles (350 km)
Regular Maintenance	every 30 riding days, about 1,000 miles (1,600 km)
Pre-ride Inspection	Check the following items each time before you ride (page 25): tires, spokes & rims, leaks, engine oil, fuel, drive chain, cables, nuts & bolts, throttle, brakes, and clutch lever
Fuel/Capacity	unleaded gasoline, pump octane number of 86 or higher 6.5 ℓ (1.7 US gal, 1.43 Imp gal; reserve: 0.9 ℓ (0.24 US gal, 0.20 Imp gal)
Engine Oil	API Service Classification SF or SG; SAE 10W-40
Maximum Weight Capacity	100 kg (220 lbs) rider only (no passenger or cargo) and any accessories
Tire Pressure	Front: 100 kPa (1.0 kg/cm <sup>2</sup> , 15 psi), check while tires cold Rear: 125 kPa (1.25 kg/cm <sup>2</sup> , 18 psi)
Tire Size	Front: 2.50-19-4PR, Rear: 3.00-16-4PR
Spark Plug	CR7HSA (NGK) or U22FSR-U (NIPPONDENSO)