

Opening the Fuel Fill Cap

- 1 Open the seat.  P.52
- 2 Turn the fuel fill cap counterclockwise until it stops and remove the cap.

Closing the Fuel Fill Cap

- 1 Install and tighten the fuel fill cap firmly by turning it clockwise.
 - ▲ Make sure that the arrow marks on the cap and fuel tank are aligned.
- 2 Close the seat.

!WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.