

## Cleaning the Crankcase Breather

---

1. Place a suitable container to receive deposits.
2. Remove the crankcase breather tube plug from the tube.
3. Drain deposits into a suitable container.
4. Install the crankcase breather tube plug.

