


## Main Fuse



1. Remove the front seat. ► P. 54
2. Disconnect the wire connector of the starter magnetic switch.
3. Pull the main fuse out and check for a blown fuse. Always replace a blown fuse with a spare of the same rating.  
► Spare main fuse is provided in the starter magnetic switch.
4. Reinstall parts in the reverse order of removal.