

When “---” is displayed except for the above-mentioned cases, go to your dealer for service.

To reset the average fuel mileage:

(P37)

Average speed

Displays the average speed since the selected tripmeter was reset.

The average speed will be calculated based on value displayed on the tripmeter (A or B) selected. Also, the average speed for tripmeter A will be displayed when the odometer is selected.

- Initial display: “---” is displayed.

When “---” is displayed while riding, go to your dealer for service.

To reset the average speed: (P37)