

Shifting Gears *(Continued)*

Neutral (N):

Neutral is selected automatically when you turn the ignition switch to ON.

If neutral is not selected when you turn the ignition switch to ON:

- u Turn the ignition OFF and ON again.
- u If neutral is still not selected after turning the engine off then on again. (P141)
You may hear (click) noises when the transmission shifts to Neutral (N). This is normal.

When you can change between N and D

- u Motorcycle is stopped and the engine is idling.
- u Throttle is completely closed. It is not possible to change from Neutral to D mode while the throttle is applied.
- u You cannot change between N and D mode while the wheels are rotating.
- u Side stand is raised.

NOTICE

To prevent clutch damage, do not use the throttle to keep the motorcycle stopped uphill.