



# Indicators

If one of these indicators does not come on when it should, have your dealer check for problems.

## ← Left turn signal indicator

### **PGM-FI (Programmed Fuel Injection) malfunction indicator lamp (MIL)**

Comes on briefly when the ignition switch is turned to the ON position with the engine stop switch in the  (Run) position.

Comes on when the ignition switch is turned to the ON position with the engine stop switch in the  (Off) position.

**If it comes on while engine is running:** 

### **Low oil pressure indicator**

Comes on when the ignition switch is turned to the ON position.

Goes off when the engine starts.

**If it comes on while engine is running:** 