


Shifting Gears *(Continued)*

S mode level selecting while in AT MODE


While in S mode, press and hold the **D-S** side of the N-D (1) switch.

- ▶ Close the throttle completely. Then select the desired level of the S mode.



- ↷ Press and hold the **D-S** side of the N-D switch
- ➡ Press the **D-S** side of the N-D switch

N-D switch



The selected level is maintained even when the ignition switch is turned to the OFF position, or transmission is switched to out of S mode.