


Handle grip heater status icon

CRF1100A4/D4

The handle grip heater status icon will appear while the handle grip heater is on. 

If the handle grip heater status icon flashes: 

Gear position indicator

CRF1100A/A4

The gear position is shown in the gear position indicator.
 u “-” appears when the transmission is not shifted properly.

CRF1100D/D4

The gear position is shown in the gear position indicator.
 The indicator may flash if:

- u The front wheel leaves the ground.
- u You turn the wheel while the vehicle is upright on the stand.

This is normal. To operate the system again, turn the ignition switch to the OFF position, and then to the ON position again.

D is shown in the gear position indicator when the D mode is selected in the AT MODE.

S is shown in the gear position indicator when the S mode is selected in the AT MODE.

 **S mode level indicator** 

If the “-” indicator is blinking in the gear position window while riding: 