



Cleaning

RIGHT SIDE



- (1) screw
- (2) air cleaner housing cover



- (3) set spring
- (4) set spring holder
- (5) air cleaner

1. Remove the right side cover ([page 57](#)).
2. Remove the screws (1) and air cleaner housing cover (2).
3. Unhook the set spring (3), take care to avoid bending the set spring and set spring holder (4).
4. Remove the air cleaner (5).

(cont'd)