

Quick Reference

Initial Maintenance	about 100 miles (150 km) or 1 month.
Regular Maintenance	about every 600 miles (1,000 km) or 6 months.
Pre-ride Inspection	Check the following items each time before you ride (page 22): tires, spokes & rims, leaks, engine oil, fuel, drive chain, cables, nuts & bolts, spark plug & cap, throttle, brakes, and clutch lever.
Fuel/Capacity	unleaded gasoline, pump octane number of 86 or higher tank: 1.59 US gal (6.0 ℓ) reserve: 0.34 US gal (1.3 ℓ)
Engine Oil/Capacity	API Service Classification SG or higher except oils labeled as energy conserving or resource conserving on the circular API service label, SAE 10W-30, JASO T 903 standard MA, Pro Honda GN4 4-stroke oil (USA & Canada), or Honda 4-stroke oil, or an equivalent motorcycle oil after draining: 1.5 US qt (1.4 ℓ) after draining and oil filter change: 1.5 US qt (1.4 ℓ)
Maximum Weight Capacity	220 lb (100 kg) rider only (no passenger or cargo) and any accessories
Tires	Front: 80/100-21 51R NHS Rear: 100/100-18 59R NHS Type: bias-ply, tube
Tire Pressure (cold)	Front: 15 psi (100 kPa, 1.0 kgf/cm ²) Rear: 15 psi (100 kPa, 1.0 kgf/cm ²)
Spark Plug	LMAR7H-9DS (NGK)
Fuse	main: 10 A sub: 7.5 A