

## Adjusting the Clutch Lever Freeplay

### Minor Adjustment

Attempt adjustment with the minor clutch cable adjuster first.

1. Pull back the rubber dust cover.
2. Loosen the minor lock nut.
3. Turn the minor clutch cable adjuster until the freeplay is 10 to 20 mm (0.4 to 0.8 in).
4. Tighten the minor lock nut and check the freeplay again.
5. Install the rubber dust cover.

