



11. Make sure the plug washer is in good condition.
12. Install the spark plug. With the plug washer attached, thread the spark plug in by hand to prevent cross-threading.
13. Tighten the spark plug:
 - If the old plug is good:
1/8 turn after it seats

- If installing a new plug, tighten it twice to prevent loosening:
 - a) First, tighten the plug:
NGK: 1/2 turn after it seats.
DENSO: 3/4 turn after it seats.
 - b) Then loosen the plug.
 - c) Next, tighten the plug again:
1/8 turn after it seats

NOTICE

An improperly tightened spark plug can damage the engine. If a plug is too loose, a piston may be damaged. If a plug is too tight, the threads may be damaged.

14. Install the parts in the reverse order of removal.
 - When reinstalling the spark plug cap, take care to avoid pinching any cables or wires.