## **Electrical Trouble**

## **Battery Goes Dead**

Charge the battery using a motorcycle battery charger.

Remove the battery from the scooter before charging.

Do not use an automobile-type battery charger, as these can overheat a motorcycle battery and cause permanent damage. If the battery does not recover after recharging, contact your dealer.

## NOTICE

Jump starting using an automobile battery is not recommended, as this can damage your scooter's electrical system.

## **Burned-out Light Bulb**

Follow the procedure below to replace a burned-out light bulb.

Turn the ignition switch to the OFF or **?** (Lock) position.

Allow the bulb to cool before replacing it.

Do not use bulbs other than those specified.

Check the replacement bulb for correct operation before riding.

For the light bulb wattage, see "Specifications." ■ P. 119