

Fuel

Fuel Capacity

Fuel tank capacity, including reserve:

3.88 US gal (14.7 ℓ)

Reserve capacity:

1.29 US gal (4.9 ℓ)

Except TRX420TM1:


When there is only one segment left in the fuel gauge (page 25), fuel will be low and you should refuel as soon as possible.

TRX420TM1 only:

The tank should be refilled as soon as possible when the fuel warning indicator comes on.

Refueling Procedure

Refer to *Safety Precautions* on page 103.



(1) fuel fill cap

(2) bottom of the filler neck