## (VT1300CXA only)

When removing and installing the wheel, be careful not to damage the wheel speed sensor and pulser ring.

## I Front Wheel

## Removal

- 1. Park on a firm, level surface.
- **2.** Remove the fixing bolts and remove the left brake caliper assembly from the fork leg.
  - Support the brake caliper assembly so that it doesn't hang from the brake hose. Do not twist the brake hose.
  - Avoid getting grease, oil, or dirt on the disc or pad surfaces.
  - ➤ Do not pull the brake lever while the brake caliper is removed.
- 3. Remove the front axle bolt.
- **4.** Loosen the right and left axle pinch bolts.



