

## Throttle Inspection

Refer to *Safety Precautions* on page 58 .

1. Check that the throttle assembly is positioned properly and the securing bolts are tight.
2. Check for smooth rotation of the throttle from fully open to fully closed in all steering positions. If there is a problem, see your dealer.