

# Starting

## Starting the Engine

Start your engine using the following procedure, regardless of whether the engine is cold or warm.

This scooter is equipped with a side stand ignition cut-off system.

- ▶ If the side stand is down, the engine cannot be started.
- ▶ If you lower the side stand with the engine running, it will automatically shut off.

### NOTICE

- If the engine does not start within 5 seconds, turn the ignition off and wait 10 seconds before trying to start the engine again to recover battery voltage.
- Extended fast idling and reving the engine can damage the engine, and the exhaust system.
- The engine will not start if the throttle is fully open.

- Place the scooter on its center stand.
- Lock the rear wheel by squeezing the rear brake lever (a ) and setting the rear brake lock (b ).
  - ▶ The starter motor will only work when the rear brake lever is pulled and the side stand is up.

