


## Adjusting the Clutch Lever Freeplay

### Upper Adjustment

Attempt adjustment with the upper clutch cable adjuster first.

1. Pull back the rubber dust cover.
2. Loosen the upper lock nut.
3. Turn the upper clutch cable adjuster until the freeplay is  $\frac{3}{8}$  to  $\frac{13}{16}$  in (10 to 20mm).
4. Tighten the upper lock nut and check the freeplay again.
5. Install the rubber dust cover.



### Lower Adjustment

If the minor clutch cable adjuster is threaded out near its limit, or the correct freeplay cannot be obtained, attempt adjustment with the lower adjusting nut.