

3. Check that the O-rings on the oil filter bolt and cover are in good condition and install the cover.
Oil filter bolt torque: 28–32 N·m (2.8–3.2 kg·m, 20–23 ft-lb)
4. Fill the crankcase with approximately 3.5 liters (3.7 U.S. qt., 3.1 Imp. qt.) of the recommended oil.
5. Install the oil filler cap.
6. Start the engine and let it idle for 2–3 minutes.
7. Stop the engine and check that the oil level is at the upper level mark on the dipstick. Make sure there are no oil leaks.

-
3. Revise que los anillos O del tornillo del filtro de aceite y los de la cubierta estén en buen estado y monte la cubierta.

Torsión de aprieto del tornillo del filtro de aceite:

28–32 N·m (2,8–3,2 kg·m)

4. Rellene el cárter con aproximadamente 3,5 litros del aceite recomendado.
5. Monte la tapa del llenador de aceite.
6. Arranque el motor y déjelo girar en vacío durante dos o tres minutos.
7. Apague el motor y revise que el nivel de aceite esté al ras de la marca de nivel superior de la varilla probadora de aceite. Asegúrese de que no hay ningún escape de aceite.