

To replace the fuses in the fuse box, remove the fuse box cover. Pull the old fuse out of the clips; or slide it lengthwise until one end comes out, then lift it out with your fingers. Push a new fuse into the clips and install the box cover.

WARNING:

- Never use a fuse with a different rating from that specified. Serious damage to the electrical system or a fire may result, causing a dangerous loss of lights or engine power at night or in traffic.
- Do not pry the clips open to get a fuse out; you could bend them and cause poor contact with the new fuse. A loose fuse could cause damage to the electrical system and even start a fire.

Para poner los fusibles en la caja de fusibles, extraer la tapa de la caja de fusibles. Tirar del fusible fundido para extraerlo de su sujetador; o deslizarlo longitudinalmente hasta que salga un extremo, luego levantarlo con los dedos. Poner a presión el fusible nuevo en el sujetador e instalar la tapa de la caja de fusibles.

ATENCION:

- No utilizar jamás fusibles con un amperaje diferente del especificado. Se podría dañar seriamente el sistema eléctrico o provocar fuego, causando peligrosas pérdidas de la luz o potencia del motor por la noche o en el medio del tráfico.
- No presionar los sujetadores para abrirlos a fin de extraer el fusible; se podría doblarlos y causar malos contactos con el fusible nuevo. Un fusible flojo puede causar daños en el sistema eléctrico pudiendo incluso provocar un incendio.