

RIDING THE MOTORCYCLE

WARNING:

- Exhaust pipe and muffler become very hot during operation and remain sufficiently hot to inflict burns if touched, even after shutting off the engine. Wear clothing which will completely cover the legs while riding and avoid any contact with unshielded portions of the exhaust system.
- Do not wear loose clothing which may catch on control levers, starter pedal, foot pegs, wheels and tires.
- Ensure that all required equipment as specified by local laws and regulations is installed on the motorcycle and operable before riding it on public streets.
- Modification of the motorcycle, or removal of original equipment may render the vehicle unsafe or illegal.
- Review Motorcycle Safety (page 8-14) before you ride.
- Make sure the side stand is fully retracted before riding the motorcycle.

NOTE: Make sure the function of the side stand mechanism. (See MAINTENANCE SCHEDULE on page 107 and explanation for SIDE STAND on page 134.)

MONTA EN LA MOTOCICLETA

ATENCION:

- El tubo de escape y el silenciador se calientan mucho durante el funcionamiento y permanecen lo suficientemente calientes como para causar quemaduras durante algún tiempo después de parar el motor. Póngase ropa que le cubra totalmente las piernas al montar y evite el contacto con las porciones no protegidas del sistema de escape.
- No lleve ropas sueltas que puedan engancharse en las palancas de mando, pedal de arranque, apoyapiés, ruedas y neumáticos.
- Cerciórese de que todo el equipo necesario está instalado en la motocicleta y que está en perfecto estado de funcionamiento, tal como lo disponen las leyes y regulaciones locales, antes de circular por la vía pública.
- La modificación de la motocicleta o el desmontaje de equipos originales puede convertir al vehículo en inseguro o ilegal.
- Revisar el apartado "Seguridad de la motocicleta" (página 8 a la 14) antes de conducir.
- Asegurarse de que el soporte lateral esté completamente plegado antes de conducir la motocicleta.

NOTA: Asegurarse de que el mecanismo del soporte lateral funcione perfectamente. (Consultar el PROGRAMA DE MANTENIMIENTO de la página 109 y las explicaciones para el SOPORTE LATERAL de la página 134.)