

Ref. No.	Description	Function
5	Tachometer red zone	<b>CAUTION:</b> Exceeding recommended maximum engine rpm may cause serious engine damage.
6	Turn signal indicator (amber)	Flashes when either turn signal operates.
7	High beam indicator (blue)	Lights when headlight is on high beam.
8	Neutral indicator (green)	Lights when transmission is in neutral.
9	Tripmeter reset knob	Resets tripmeter to zero (0). Turn knob in direction shown.

No de referencia	Descripción	Función
5	Zona roja del tacómetro	<b>PRECAUCION:</b> El motor se dañará seriamente si se excede el máximo de rpm del motor que han sido recomendadas.
6	Indicador del intermitente de viraje (ambar)	Destella cuandoquiera que funcione uno de los intermitentes de viraje.
7	Indicador de luz larga (azul)	Se ilumina cuando el faro tiene la luz larga.
8	Indicador de punto muerto (verde)	Se ilumina cuando la transmisión está en punto muerto.
9	Mando de reposición a cero del odómetro para viajes	Girar el mando hacia la izquierda para poner el odómetro a cero.