

MOTORCYCLE SAFETY

- Cargo weight should be carried as low and as close to the centre of a motorcycle as possible. When loading your motorcycle, try to pack heavier items in the saddlebags and put lighter, bulkier items in the travel trunk. If you must carry heavy items in the trunk, put them as far forward as you can.
- Balance cargo weight evenly on both sides. When loading the saddlebags, for example, be sure the weight in each bag is about the same.

Attachments and Modifications

Modifying this motorcycle or improperly attaching police equipment can make it unsafe. Before making any modifications or attaching any equipment, be sure to read the following information.

WARNING

Improper modifications or addition of police equipment can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding attachments and modifications.

Attachments

Because Honda cannot test all available equipment or combinations of equipment that may be required for use on a police vehicle, you and your department must be responsible for the proper selection, installation, and use of equipment attached to this vehicle.

We strongly recommend that qualified personnel evaluates a motorcycle fitted with all required police equipment under the anticipated conditions before the vehicle is placed into service.

Always follow these guidelines:

- Make sure any added equipment does not obscure any lights, reduce ground clearance and lean angle, limit suspension travel or steering travel, alter riding position, or interfere with operating any controls.