



Fig. 4-32 Points to secure Sportrax with tie downs

(3) Left footpeg
(4) Rear carry pipe or Rear axle shaft

If it is necessary to incline your Sportrax upright on the rear end:

1. Follow steps 1 and 2 on the previous page.
2. Place a suitable container under the carburetor drain tube.
3. Turn the drain screw counterclockwise and drain the fuel from the carburetor.
4. After draining the carburetor, turn the drain screw clockwise until it is tight.
5. Pour the drained fuel into the fuel tank.
6. Tilt the vehicle and secure properly.

Do not tow your Sportrax behind a car or other vehicle.