

- Fit the caliper over the disc taking care not to damage the brake pads. Install the caliper fixing bolts and tighten to 20–30 N·m (2.0–3.0 kg-m, 15–22 ft-lb) torque.
- After installing the wheel, apply the brake several times and check for free wheel rotation when released.

WARNING: If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly.

-
- Poser l'étrier par dessus le disque en veillant à ne pas endommager les plaquettes de frein. Remettre les boulons de fixation d'étrier en place et les serrer au couple recommandé de 20 à 30 N·m (2,0 à 3,0 kg-m).
 - Après avoir remonté la roue, appuyer plusieurs fois sur le frein et vérifier que la roue tourne bien librement lorsqu'on le relâche.

ATTENTION: Si une clé dynamométrique n'a pas été utilisée pour reposer la roue, faire vérifier le montage par un concessionnaire-Honda aussitôt que possible.