


**WARNING**

- \* *Always turn the engine off before performing any maintenance operations, unless otherwise stated.*
- \* *To maintain the safety and reliability of your HONDA ATC do not modify it. Use only new genuine HONDA parts or their equivalent when servicing or repairing.*  
*The use of replacement parts which are not of equivalent quality may impair the operation of your ATC.*

## TOOL KIT

The tool kit (1) is stored under the seat as shown below. The tools provided are sufficient to perform routine maintenance and simple repairs. Any extensive work requiring additional tools should be performed by an authorized Honda motorcycle dealer.

- Screw driven blade
- Handle for screw driver
- 10 x 12 mm open end wrench
- 14 x 17 mm open end wrench
- Pliers
- 17 mm box wrench
- Handle bar B
- 24 mm box end wrench
- Tool bag



(1) Tool kit