

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean      R: Replace A: Adjust		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page	
	DRIVE CHAIN		I.L	I.L	49
*	BRAKE PAD WEAR	NOTE (3)	I: (EVERY YEAR)		46
	CHAIN SLIDER		I	I	50
	FRONT FORK OIL/AIR		R: (EVERY YEAR)		16
	FRONT/REAR BRAKE FLUID		I	I R: (EVERY YEAR)	44
*	SUSPENSION			I	—
	SWINGARM BEARING		I.L	I.L	—
*	CLUTCH		A	A	42
*	SPARK ARRESTER			C	51
	ALL NUTS, BOLTS, FASTENERS		I	I	—
	LIGHTING EQUIPMENT		I	I	—
	TIRES		I	I	14
*	STEERING HEAD BEARING		A: (EVERY YEAR)		—

NOTE: (3) Service more frequently after riding in very wet or muddy conditions.