


**WARNING**

- \* *Always turn the engine off before performing any maintenance operations unless otherwise stated.*
- \* *To maintain the safety and reliability of your HONDA ATC, do not modify it and use only new genuine HONDA parts or their equivalent when servicing or repairing.*  
*The use of replacement parts which are not of equivalent quality may impair the operation of your ATC.*

## TOOL KIT

The tool kit is stored under the seat (1) as shown below. The tools provided are sufficient to perform routine maintenance and simple repairs. Any extensive work requiring additional tools should be performed by an authorized Honda motorcycle dealer.

- Pin spanner
- Hex wrench
- 14 x 21 mm box wrench
- Pliers
- Screwdriver
- Grip for screwdriver
- 8 x 12 mm open end wrench
- 10 x 14 mm open end wrench
- Tool bag



(1) Tool kit