

## PRE-RIDE INSPECTION

### WARNING

\* *If the Pre-ride Inspection is not performed, serious damage or an accident may result.*

Inspect your ATC 250R every day before you ride it. The items listed here will only take a few minutes, and in the long run they can save time, expense, and possibly your life.

1. Fuel level-fill fuel tank when necessary (page 11).  
Check for leaks.
2. Coolant level – add coolant if required.  
– check for leaks (page 14).
3. Brakes-check operation and fluid level (page 50 – 53).
4. Tires-check condition and pressure (page 18).
5. Drive chain-check condition and slack (page 55).  
Adjust and lubricate if necessary (particularly the master link).
6. Throttle-check for smooth opening and closing in all steering positions (page 54).
7. Headlight switch-check for proper function (page 5).
8. Ignition switch-check for proper function (page 5).

9. Nuts, bolts, fasteners-check wheels to see that axle nuts are tightened and secured by cotter pins. Check security of all other nuts, bolts and fasteners.

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.