


ENGINE OIL LEVEL

To check the oil level, place the vehicle on level ground and insert the dipstick ① by putting the oil filler cap in position. Do not screw it in. The oil level should be between the upper ② and lower ③ marks on the dipstick.



- ① Dipstick
- ② Upper oil level mark
- ③ Lower oil level mark

THROTTLE LEVER

The throttle lever ① is located at the right handlebar grip and is operated by the rider's thumb. Pressing the lever forward opens the throttle. When the lever is released, spring tension closes the throttle automatically.



- ① Throttle lever