

PRE-RIDING INSPECTION

Before riding your ATC-70, inspect the following items for safe riding. This inspection will take only a few minutes and can save you much time and expense in the long run.

1. Engine Oil Level

Check engine oil level and add if necessary.

2. Fuel

Check the amount of fuel in the tank and refill if necessary.

3. Brake

Check operation and brake lever free play. Adjust if necessary.

4. Tire Pressure

Check the tire pressure.
Recommended Pressure:
0.2 kg/cm² (3.0 psi)

5. Bolts, Nuts and Fittings

Check wheels to see that axle nuts

are tightened and secured by cotter pins. Check all bolts, nuts and fittings for looseness and retighten if necessary.

