

**REGULAR
SERVICE PERIOD
EVERY 30
OPERATING DAYS**

NOTE

**Change oil every
30 operating days
or every 3
months, which-
ever occurs first.**

- **ENGINE OIL** - Change.
- **SPARK PLUG** - Clean and adjust gap, or replace if necessary.
- **CONTACT POINTS AND IGNITION TIMING** - Clean check, and adjust or replace if necessary.
- **VALVE TAPPET CLEARANCE** - Check and adjust if necessary.
- **CAM CHAIN TENSION** - Adjust.
- **POLYURETHANE FOAM AIR FILTER ELEMENT** - Clean and oil. Service more frequently if operated in dusty areas.
- **CARBURETOR** - Check and adjust if necessary.
- **THROTTLE OPERATION** - Inspect cable. Check and adjust free play.
- **CLUTCH** - Check operation and adjust if necessary.
- **DRIVE CHAIN** - Check, lubricate, and adjust if necessary.
- **BRAKE CONTROL LINKAGE** - Check linkage and adjust if necessary.
- **TIRES** - Inspect and check air pressure.
- **ALL NUTS, BOLTS, AND OTHER FASTENERS** - Check security and tighten if necessary.