

## CONTENTS

---

<b>ATC SAFETY</b> .....	1
<b>SERIAL NUMBER LOCATIONS</b> .....	4
<b>DESCRIPTION</b> .....	5
<b>COMPONENT FUNCTION</b> .....	7
Ignition Switch .....	7
Brake Lever/Parking Brake .....	7
Gearshift Pedal .....	8
Neutral Indicator .....	9
Choke Lever .....	10
Fuel Valve .....	11
Fuel Tank .....	12
Fuel Drain .....	13
Oil Recommendation .....	14
Engine Oil Level .....	15
Throttle Lever .....	15

Speed Limiter .....	16
Step Guard .....	17
Tires .....	18
<b>PRE-RIDE INSPECTION</b> .....	19
<b>STARTING THE ENGINE</b> .....	20
<b>BREAK-IN PROCEDURE</b> .....	21
<b>RIDING THE HONDA ATC</b> .....	23
Turning Maneuvers .....	24
Climbing Hills .....	28
Descending Hills .....	30
Traveling Slopes .....	31
Riding Through Water .....	32
Tire Care .....	33
<b>MAINTENANCE</b> .....	34
Maintenance Schedule .....	34
Tool Kit .....	36