


Rebound damping adjuster

The damping adjuster (1) provides the desired amount of damping under various riding conditions, and can be adjusted to any one of three positions.

NOTE:

- Be sure the damping adjusters are not between positions but are firmly located in a detent.
- Be sure to adjust both shock absorber to the same positions.



Ajustador del amortiguamiento

El ajustador del amortiguamiento (1) proporciona la cantidad deseada de amortiguamiento bajo distintas condiciones de marcha y puede ajustarse a cualquiera de las tres posiciones.

NOTA:

- Cerciorarse de que los ajustadores del amortiguamiento no estén en posiciones intermedios sino que estén bien fijos en las posiciones con parada.
- Cerciorarse de ajustar ambos amortiguadores a las mismas posiciones.