

• The following codes in this manual indicate each country.

TU	Turkey	IITU	(TU Type II)
	Ukraine		
U	Australia	IIU	(U Type II)

The illustrations herein are based on the IITU type.
The specifications may vary with each locale.
This vehicle pictured in this owner's manual may not match your actual vehicle.

