


**To set scheduled date:**

1. Turn the ignition switch ON.
2. Select the DAYS mode.
3. Press the left control button (1) for more than 2 seconds. The display will be set in the adjustment mode with the year display flashing.



- (1) Left control button  
(2) Right control button

4. To set the year, press the right control button (2) until the desired year appears.
  - Quick setting — press and hold the right control button until the desired year appears.
  - If setting “-.” while adjusting year, scheduled date is not set.
5. Press the left control button when the display reaches the desired year. The month display will be flashing.

