

TOOL KIT


The tool kit (1) is stored in the tool compartment under the right side cover.

To open the tool compartment, insert the ignition key (2) and turn it clockwise to unlock.

To close the tool compartment, close the compartment cover and turn the ignition key counterclockwise to lock.

Some roadside repairs, minor adjustments and parts replacement can be performed with the tools contained in the kit.

- 10 x 12 mm open end wrench
- 14 x 17 mm open end wrench
- Pliers
- Standard/phillips screwdriver
- Screwdriver grip
- 22 mm box end wrench
- Pin spanner
- Breaker bar
- Spark plug wrench
- Handle bar
- Tool bag



(1) Tool kit
(2) Ignition key